
Meridian Administration Tools

Alarm and Event Management

User Guide

Document Number: P0843840

Document Release: Standard 5.7

Date: October 1997

© 1996, 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules.

MAT and Meridian 1 are trademarks of Northern Telecom.

Contents

Alarm and Event Management	1
Alarm Banner	3
Launching the Alarm Banner	4
Alarm Notification	5
Events window	7
Using the Events window	7
Launching the Events window	8
Getting around in the Events window	9
Events window menus	11
Determining the cause of an alarm	12
Acknowledging an alarm that you intend to clear	12
Learning more detail about an alarm	13
Changing alarm severity or escalation	13
Viewing the Event Default Table	14
Creating and customizing event preferences	14